JB907


Three-Position Plugs for Single-Axis Input and Output Junction Boxes



JB907-1A







Three-Position Plug, Spring Cage, for use in JB, SB, MX, and CR Single-Axis Junction Boxes

JB907-2A








Three-Position Plug, Screw Terminal, for use in JB, SB, MX, and CR Single-Axis Junction Boxes

JB907-3A





Three-Position "T" Plug, Screw Terminal, for use in JB, MMX, and SSB Single-Axis Compatible Junction Boxes for Continuous Output