


JB930

Four-Position Plugs for Dual Input and Output Junction Boxes




JB930-1A




Four-Position Plug, Spring Cage, for use in DSB, JB, and SB Dual Input and Output Junction Boxes

JB931-1A



Four-Position Plug, Screw Terminal, for use in JB and SB Dual Input and Output Junction Boxes

JB931-3A



Four-Position "T" Plug, Screw Terminal, for use in DSB Dual Input and Output Junction Boxes